

Amplifier Setup Checklist

1) DIP SWITCH SETTING TO Current Mode →

1	2	3	4	5	6	7	8	9
OFF	OFF	ON	OFF	ON	OFF	OFF	ON	OFF

SW 10 = OFF

Pot 1 = Fully CCW

Pot 2 = Fully CW (max current)

Pot 3 = Fully CW (max Ref Gain)

Pot 4 = offset Adjust -- set so output $\equiv 0$ when input $\equiv 0$
then ~~turn~~ 4 turns CW

If Motors won't move

also check driver load option

under Moticon.exe Startup

to see if it loaded successfully w/ DGRAM