SERVO ENCLOSURE

X AXIS Y AXIS Z AXIS

X AXIS AMPLIFIER

Y AXIS AMPLIFIER

Z AXIS AMPLIFIER

EXHAUST! DO NOT BLOCK!

RAKO ENGINEERING

1161 Tasman Dr. Sunnyvale CA 94089
P.O. Box 61387 Sunnyvale CA 94088
PHONE: (408) 745-1994
FAX: (408) 745-6073

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES
TOLERANCES ARE:

7/11/01

FRONT PANEL GRAPHICS

DO NOT SCALE DRAWING